



The Universal–Accessible Garden’s Multi–Tiered Raised Bed

Materials: 2” x 8” x 10’ boards
Corner brackets (from Lee Valley Tools)
Screw driver
Saw
Measuring tape
Rubber headed mallet

Cut the 2”x8”x10’ boards in desired lengths (We used 5’ lengths).

Position the corner brackets in desired location. Tap into place with rubber headed mallet.

Slide board into the corner bracket, screw into place.

Repeat to form desired pattern.

To increase height, slide corner bracket into bottom corner bracket, slide 5’ board into the bracket and secure with screws.

Fill with soil and plant.



Drip irrigation on each bed.

